

Metal letter installation instructions

Supplies needed

Duct tape or heavy duty tape
Marker
Hammer drill
Heavy duty masonry drill bits
Silicone
Generator (possible)
Extension cords
Ladder (possible)
Air blower
Rubber mallet
Bolt cutter
Silicone gun w/ silicone
Safety glasses

Boxes should contain letter, studs and template.

This part is pre installation.

Remove letters from box.

Remove 1 letter at a time from the plastic wrap.

Screw the studs into back of the letters.

Place these back into the same card board box them came in face down.

Place the letters back to back with the studs not touching the edges or face of the letters.

Place a layer of cardboard on that layer and if needed foam cushion.

Continue studding the letter and layering with cardboard between each layer.

At the job site

Locate the template on the wall.

Secure it with duct tape or equivalent.

Make sure the template is level.

(If the wall is brick or has horizontal lines, make sure the template is parallel with the brick)

The template will be marked when the holes are to be drilled.

Drill into the center of the marks.

Drill deep enough, and wide enough to accommodate the length and width of the studs.

When all the holes are drilled and dry tested, remove the template.

Blow the debris out of the holes with canned air or a portable blower.

Apply silicone to the holes and a little around the stud.

Slide the studded letters into the holes.

If the letters are not perfectly plumb, they can be manipulated a little by tapping them with a rubber mallet.

Step back and admire the beauty! If it's not beautiful, then you need to rework some of the letters.

Good luck and give us a call if you have any questions at all. 1-800-322-1515.